

# Assembly Instruction

**2. Push and click down into place, and make sure back is fully secure.**



**1. Lift back loose cover upright, so metal brackets and reciever are aligned.**

